

HERAKLES NEO



Firmware HERAKLES NEO Ladegerät V1.23

Anleitung:

1. Speichern und entpacken Sie die Datei auf Ihrem Rechner.
2. Verbinden Sie das Ladegerät mit der Stromversorgung (Steckdose oder Akku).
3. Verbinden Sie das Ladegerät und PC mit einem Micro USB-Kabel.
4. Warten Sie bis die automatische Treiberinstallation abgeschlossen ist.
5. Öffnen Sie die exe-Firmware-Software.
Warten Sie, bis die Software „Charger Ready“ anzeigt.
Wenn sich die Software nicht öffnet, installieren Sie bitte „dotNetFx40_Full_x86_x64“.
6. Drücken Sie auf die Schaltfläche „Aktualisieren“. Dieser Vorgang kann mehrere Minuten dauern.
Falls Sie eine Fehlermeldung bekommen, trennen Sie NICHT das Ladegerät vom PC!
Versuchen Sie den Vorgang „Aktualisieren“ erneut. Bei weiteren Problemen kontaktieren Sie uns bitte.

Firmware HERAKLES NEO Charger V1.23

Instruction:

1. Download and unzip the file on your computer.
2. Connect the charger to a power supply.
3. Connect the charger to your PC with a USB micro cable.
4. Wait until the automatic driver installation is complete.
5. Open the exe-firmware software.
Wait till the Software shows „Charger Ready“.
If the software does not open, please install „dotNetFx40_Full_x86_x64“.
6. Press the „Update“ button. This process can take several minutes.
If you get an error message, DO NOT disconnect the charger from the PC!
Try the update process again. If you have any further problems, please contact us.

developed by racers for racers